

# Starlite

## Garden Torche™



### Instructions

Fill the Torche in 1-1/2 inches from the top with lamp oil or an insect repelling lamp oil such as Citronella. Remove the Torche cap by grasping the torche and cap and lifting up on the cap.

Light the wick with caution. The wick should extend 3/4 inch above the cap and must be saturated with oil before lighting. The Starlite Garden Torche has a fiberglass wick that will not burn away. Only the oil burns. After the Wick becomes saturated with lamp oil the Starlite Garden Torche can remain outdoors year round. There is no need for concern after rain or snow. The Starlite Garden Torche will light. Always keep lamp oil in the Torche to ensure performance.

Blow the flame to extinguish.

Enjoy years of satisfaction with your Starlite Garden Torche. Simply keep it clean and filled with lamp oil. When not in use for long periods of time, occasionally remove the cap and spread oil underneath it to prevent oxidation.

### Caution

For outdoor use only.

For use with Lamp Oil Only.

Never use Gasoline, Kerosene, Alcohol of any kind, Lighter Fluids, Solvents or any other fuel other than Lamp Oil.

Never leave burning flames unattended.

Never place combustibles near an open flame, i.e.: Wood structures, fuels, clothing, umbrellas, awnings, vegetation, etc.

Keep out of reach of children. Starlite Garden Torches are for adult use only.

Copyright 2000 Starlite Corporation. All Rights Reserved.

Starlite Garden Torche Co.  
315 Waynetown Rd  
Crawfordsville In. 47933